

## Q-Logic: Q-Forms & Q-Customs Application Guide

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Acura												
CL 1997-99	6004B/C			01			42,55		43			45
Integra 1994-99	7001B/C			01			42,55		47	53		
RSX 2002-06	7002B/C	RSX110A		01			42,55		47	53		
TL 1999-03	6006B/C			01	40		A5,B2			44		
BMW												
3-Series Coupe 1993-99	9001B (10)			01	64		65,84		67	66		
Buick												
Grand National 1984-87	1011B/C			01	12	10	11			14		
Rainier 2004-07	1016B/C (3)	GTE110 (3)		01			C0,C5,73	E3	73	E2		
Regal 1978-87	1011B/C			01	12	10	11			14		
Cadillac												
Escalade 1999-00	1007B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80		13,16			
Escalade 2002-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Escalade 2007-09	1017C (1)	GMA110 (1)		01			C5		E5			
Escalade EXT 2007-09	1017C			01			C5		E5			
Chevrolet												
Avalanche 2002	1012B/C (1,5)	GMA110/SYT108 (1,5)		01	12,86	A3	80,85		A2	19		
Avalanche 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Avalanche 2007-09	1017C (1)	GMA110 (1)		01			C5		E5			
C10 1978-87	1006C			01	39	10	08			14		
C20 1978-87	1006C			01	39	10	08			14		
C30 1978-87	1006C			01	39	10	08			14		
Camaro 1982-92	1002B/C	ECF210/212		01	12	17	11,81,09			14		
Camaro 1993-02	1005B/C	CFT210/212		01		18	11,80		16,13	19,75,14		
Cavalier 1991-94	1008B/C (4)			01	77,76		94,78		13,16	14,19		
Cavalier 1995-96	1009B/C (4)			01	76		80		16	19		
Cavalier 1997-05	1010B/C (4)			01			80		A2	19		
El Camino 1978-87	1011B/C			01	12	10	11			14		
K5 Blazer 1978-91	1006C			01	39	10	08			14		
K5 Blazer 1992-94	1001C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80,08		13,16	14		
Monte Carlo 1978-88	1011B/C			01	12	10	11			14		
S10 Blazer 1982-94	1003B/C			01	12	10	11		13	15		
S10 Blazer 1995-04	1004B/C			01	12		11		13,A2	19		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Chevrolet												
Suburban 1978-91	1006C			01	39	10	08			14		
Suburban 1992-94	1001B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80,08		13,16	14		
Suburban 1995-98	1007B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80		13,16			
Suburban 1999	1007B/C (5,6,7)	SYT108/SYT110D/P (5,6,7)		01	12	10,A3	11,80		13,16			
Suburban 2000-02	1012B/C (1,5)	GMA110/SYT108 (1,5)		01	12,86	A3	80,85		A2	19		
Suburban 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Suburban 2007-09	1017C		SUV212	01			C5		E5			
Tahoe 1995-98	1007B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80		13,16			
Tahoe 1999	1007B/C (5,6,7)	SYT108/SYT110D/P (5,6,7)		01	12	10,A3	11,80		13,16			
Tahoe 2000-02	1012B/C (1,5)	GMA110/SYT108 (1,5)		01	12,86	A3	80,85		A2	19		
Tahoe 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Tahoe 2007-09	1017C		SUV212	01			C5		E5			
Trailblazer 2002-08	1016B/C (3)	GTE110 (3)		01			C0,C5,73	E3	73	E2		
Trailblazer 2009	1016B/C			01			C0,C5,73	E3	73	E2		
Z28 1982-92	1002B/C	ECF210/212		01	12	17	11,81,09			14		
Z28 1993-02	1005B/C	CFT210/212		01		18	11,80		16,13	19,75,14		
C/K 1500 Extended Cab 1988-94	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
C/K 1500 Extended Cab 1995-98	1007B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16			
C/K 1500 Standard Cab 1988-94	1001B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 1500 Standard Cab 1995-98	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 2500 Extended Cab 1988-94	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
C/K 2500 Extended Cab 1995-98	1007B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16			
C/K 2500 Regular Cab 1988-94	1001B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 2500 Regular Cab 1995-98	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 3500 Extended Cab 1988-94	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
C/K 3500 Extended Cab 1995-98	1007B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16			
C/K 3500 Regular Cab 1988-94	1001B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 3500 Regular Cab 1995-98	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
S10 Pickup Crew Cab 2003-04	1004B/C			01	12		11		13,A2	19		
S10 Pickup Extended Cab 1982-93	1003B/C			01	12	10	11		13	15		
S10 Pickup Extended Cab 1994-03	1004B/C			01	12		11		13,A2	19		
S10 Pickup Regular Cab 1982-93	1003B/C		UTC110 (8)	01	12	10	11		13	15		
S10 Pickup Regular Cab 1994-03	1004B/C	GMS110	UTC110 (8)	01	12		11		13,A2	19		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Chevrolet												
Silverado 1500 Crew Cab 2001-06	1012B/C (1)	GMA110 (1)	UTC110 (1,8)	01	12,86	A3	80,85		A2	19		
Silverado 1500 Crew Cab 2007-09	1017C (1)	GMA110 (1)	UTC110 (1,8)	01			C5		E5			
Silverado 1500 Extended Cab 1999-06	1012B/C	GTX110/AMP		01	86,12	A3	80,85		A2	19		
Silverado 1500 Extended Cab 2007-09	1017C			01			C5		E5			
Silverado 1500 Regular Cab 1999-06	1012B/C		UTC110 (8)	01	12,86	A3	80,85		A2	19		
Silverado 1500 Regular Cab 2007-09	1017C		UTC110 (8)	01			C5		E5			
Silverado 2500 Crew Cab 2001-02	1012B/C (1,5)	GMA110/SYT108 (1,5)	UTC110 (1,5,8)	01	12,86	A3	80,85		A2	19		
Silverado 2500 Crew Cab 2003-06	1012B/C (1)	GMA110 (1)	UTC110 (1,8)	01	12,86	A3	80,85		A2	19		
Silverado 2500 Crew Cab 2007-09	1017C (1)	GMA110 (1)	UTC110 (1,8)	01			C5		E5			
Silverado 2500 Extended Cab 1999-06	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado 2500 Extended Cab 2007-09	1017C			01			C5		E5			
Silverado 2500 Regular Cab 1999-00	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Silverado 2500 Regular Cab 2001-06	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado 2500 Regular Cab 2007-09	1017C			01			C5		E5			
Silverado 3500 Crew Cab 2001-02	1012B/C (1,5)	GMA110/SYT108 (1,5)	UTC110 (1,5,8)	01	12,86	A3	80,85		A2	19		
Silverado 3500 Crew Cab 2003-06	1012B/C (1)	GMA110 (1)	UTC110 (1,8)	01	12,86	A3	80,85		A2	19		
Silverado 3500 Crew Cab 2007-09	1017C (1)	GMA110 (1)	UTC110 (1,8)	01			C5		E5			
Silverado 3500 Extended Cab 2001-06	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado 3500 Extended Cab 2007-09	1017C			01			C5		E5			
Silverado 3500 Regular Cab 1999-00	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Silverado 3500 Regular Cab 2001-06	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado 3500 Regular Cab 2007-09	1017C			01			C5		E5			
Silverado Classic 1500 Ext Cab 2007	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado Classic 1500 Reg Cab 2007	1012B/C		UTC110 (8)	01	12,86	A3	80,85		A2	19		
Silverado Classic 2500 Ext Cab 2007	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado Classic 2500 Reg Cab 2007	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado Classic 3500 Ext Cab 2007	1012B/C			01	12,86	A3	80,85		A2	19		
Silverado Classic 3500 Reg Cab 2007	1012B/C			01	12,86	A3	80,85		A2	19		
Chrysler												
PT Cruiser 1998-09	3012B/C	PTC210		01				98		93		
Sebring 1995-99	3004B/C (4)			01	A0		94	98		99		
Dodge												
Avenger 1995-99	3004B/C (4)			01	A0		94	98		99		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Dodge												
Durango 1998-00	3008B/C			01			94		A1	93		
Neon 1994-99	3006B/C			01			94,33		34,A4	93		
Neon 2000-05	3013B/C	DNE110		01			D1			93		
Dakota Club Cab 1997-99	3007B/C	DDX108		01			94		A1	93		
Dakota Club Cab 2000	3008B/C	DDX108		01			94		A1	93		
Dakota Club Cab 2001-04		DDX108		01								
Dakota Regular Cab 1997-99	3007B/C		UTC110 (8)	01			94		A1	93		
Dakota Regular Cab 2000	3008B/C		UTC110 (8)	01			94		A1	93		
Ram 1500 Club Cab 1994-01	3001B/C	DTX112		01	97,36	35	94,33		A1,34	93		
Ram 1500 Quad Cab 2002-07	3011B/C	DQC110/D		01	D2		D1			93		
Ram 1500 Quad Cab 2008	3011B/C			01	D2		D1			93		
Ram 1500 Regular Cab 1994-01	3001B/C		UTC110 (8)	01	97,36	35	94,33		A1,34	93		
Ram 1500 Regular Cab 2002-08	3011B/C		UTC110 (8)	01	D2		D1			93		
Ram 2500 Club Cab 1994-01	3001B/C			01	97,36	35	94,33		A1,34	93		
Ram 2500 Quad Cab 2003-08	3011B/C	DQC110/D		01	D2		D1			93		
Ram 2500 Regular Cab 1994-02	3001B/C			01	97,36	35	94,33		A1,34	93		
Ram 2500 Regular Cab 2003-08	3011B/C		UTC110 (8)	01	D2		D1			93		
Ram 3500 Club Cab 1994-01	3001B/C			01	97,36	35	94,33		A1,34	93		
Ram 3500 Quad Cab 2003-08	3011B/C	DQC110/D		01	D2		D1			93		
Ram 3500 Regular Cab 1994-02	3001B/C			01	97,36	35	94,33		A1,34	93		
Ram 3500 Regular Cab 2003-08	3011B/C		UTC110 (8)	01	D2		D1			93		
Eagle												
Talon 1990-94	3003B/C			01			91		92	93		
Talon 1995-99	3004B/C (4)			01	A0		94	98		99		
Ford												
Bronco 1992-96	2008B/C			01	24,22	28,23	26		21,20	20		
Bronco II 1983-90	2002B/C			01	24,03,22	28,02,2337,38,04,21			21	25	07	
Excursion 2000-05	2011B/C			01	B5		96		56	A6		
Expedition 1997-02	2010B/C (9)	EXP108/110		01		95	96		56	A6		57
Explorer 1991-94	2005B/C	EXP108/110		01	24,22	28,23	04,26		21	25		
Explorer 1995-96	2006B/C	EXP108/110		01	22	23	05		56			57
Explorer 1997-01		EXP108/110		01								
Mustang 1987-93	2001C (4)			01	24	28,06	05		27,21	25	07	

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Ford												
Mustang 1994-04	2003B/C			01		06	05,96		21,56	93,A6		
Mustang 2005-09	2014B/C (4)	MST112 (4)		01			42		D9			
Ranger 1983-94	2002B/C			01	24,03,22	28,02,2337,38,04,26			21	25	07	
Ranger 1995-09	2004B/C			01	22	23,95	05,96		56	A6		57
Taurus 1992-95	2009B/C			01	24,22	58,60	26		21			59
F150 Regular Cab 1992-96	2008B/C		UTC110 (8)	01	24,22	28,23	26		21,20	20		
F150 Regular Cab 1997-98	2010B/C (9)		UTC110 (9,8)	01		95	96		56	A6		57
F150 Regular Cab 1999-03	2010B/C (9)			01		95	96		56	A6		57
F150 Regular Cab 2004-09	2013B/C		UTC110 (8)	01			D8		D9			
F150 Supercab 1992-96	2008B/C		UTC110 (8)	01	24,22	28,23	26		21,20	20		
F150 Supercab 1997-99	2010B/C (9)	FFX108/208/AMP		01		95	96		56	A6		57
F150 Supercab 2000-03	2010B/C (9)	FFX110		01		95	96		56	A6		57
F150 Supercab 2004-08	2013B/C	FTX110		01			D8		D9			
F150 Supercab 2009	2013B/C			01			D8		D9			
F150 SuperCrew 2000-03	2010B/C (9)	FSC208		01		95	96		56	A6		57
F150 SuperCrew 2004-08	2013B/C	FTX110		01			D8		D9			
F150 SuperCrew 2009	2013B/C			01			D8		D9			
F150 Heritage Regular Cab 2004	2010B/C (9)		UTC110 (9,8)	01		95	96		56	A6		57
F150 Heritage Supercab 2004	2010B/C (9)	FFX110		01		95	96		56	A6		57
F250 Regular Cab 1992-98	2008B/C		UTC110 (8)	01	24,22	28,23	26		21,20	20		
F250 Supercab 1992-96	2008B/C		UTC110 (8)	01	24,22	28,23	26		21,20	20		
F250 Supercab 1997-98	2010B/C (9)	FFX108/208/AMP	UTC110 (9,8)	01		95	96		56	A6		57
F250 Supercab 1999	2010B/C (9)	FFX108/208/AMP		01		95	96		56	A6		57
F250 Super Duty Regular Cab 1999-06	2011B/C		UTC110 (8)	01	B5		96		56	A6		
F250 Super Duty Supercab 1999	2011B/C	FSX112		01	B5		96		56	A6		
F250 Super Duty Supercab 2000-06	2011B/C	FSX110		01	B5		96		56	A6		
F250 Super Duty SuperCrew 1999-06	2011B/C		UTC110 (8)	01	B5		96		56	A6		
F350 Regular Cab 1992-98	2008B/C		UTC110 (8)	01	24,22	28,23	26		21,20	20		
F350 Supercab 1992-98	2008B/C		UTC110 (8)	01	24,22	28,23	26		21,20	20		
F350 Super Duty Regular Cab 1999-06	2011B/C		UTC110 (8)	01	B5		96		56	A6		
F350 Super Duty Supercab 1999	2011B/C	FSX112		01	B5		96		56	A6		
F350 Super Duty Supercab 2000-06	2011B/C	FSX110		01	B5		96		56	A6		
F350 Super Duty SuperCrew 1999-06	2011B/C		UTC110 (8)	01	B5		96		56	A6		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Ford												
Focus SVT3 2000-07	2012B/C	FOC110		01			96		C4	93		
Focus ZX3 2000-07	2012B/C	FOC110		01			96		C4	93		
GMC												
Denali 1998-00	1007B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80		13,16			
Denali 2001-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Denali 2007-09	1017C		SUV212	01			C5		E5			
Envoy 2002-09	1016B/C (3)	GTE110 (3)		01			C0,C5,73	E3	73	E2		
K5 Jimmy 1982-91	1006C			01	39	10	08			14		
S15 Jimmy 1982-94	1003B/C			01	12	10	11		13	15		
S15 Jimmy 1995-01	1004B/C			01	12		11		13,A2	19		
S15 Pickup 1982-93	1003B/C			01	12	10	11		13	15		
S15 Pickup Ext Cab 1982-93	1003B/C			01	12	10	11		13	15		
Syclone 1991-92	1003B/C			01	12	10	11		13	15		
Typhoon 1991-93	1003B/C			01	12	10	11		13	15		
Yukon 1992-94	1001B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80,08		13,16	14		
Yukon 1995-99	1007B/C (6,7)	SYT110D/P (6,7)		01	12	10,A3	11,80		13,16			
Yukon 2000-02	1012B/C (1,5)	GMA110/SYT108 (1,5)		01	12,86	A3	80,85		A2	19		
Yukon 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Yukon 2007-09	1017C		SUV212	01			C5		E5			
Yukon XL 2000-02	1012B/C (1,5)	GMA110/SYT108 (1,5)		01	12,86	A3	80,85		A2	19		
Yukon XL 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Yukon XL 2007-09	1017C		SUV212	01			C5		E5			
C/K 1500 Club Coupe 1988-90	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
C/K 1500 Regular Cab 1978-87	1006C		UTC110 (8)	01	39	10	08			14		
C/K 1500 Regular Cab 1988-90	1001C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 2500 Bonus Cab 1978-87	1006C			01	39	10	08			14		
C/K 2500 Club Coupe 1988-90	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
C/K 2500 Crew Cab 1978-87	1006C			01	39	10	08			14		
C/K 2500 Regular Cab 1978-87	1006C		UTC110 (8)	01	39	10	08			14		
C/K 2500 Regular Cab 1988-90	1001B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
C/K 3500 Bonus Cab 1978-87	1006C			01	39	10	08			14		
C/K 3500 Club Coupe 1988-90	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
C/K 3500 Crew Cab 1978-87	1006C			01	39	10	08			14		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
GMC												
C/K 3500 Regular Cab 1978-87	1006C		UTC110 (8)	01	39	10	08			14		
C/K 3500 Regular Cab 1988-90	1001B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Sierra 1500 Crew Cab 2001-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Sierra 1500 Crew Cab 2007-09	1017C (1)	GMA110 (1)		01			C5		E5			
Sierra 1500 Extended Cab 1991-94	1001B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16	14		
Sierra 1500 Extended Cab 1995-98	1007B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16			
Sierra 1500 Extended Cab 1999-00	1012B/C	GMX110D/P		01	12,86	10,A3	11,80,08,85		13,16,A2	19		
Sierra 1500 Extended Cab 2001-06	1012B/C			01	12,86	A3	80,85		A2	19		
Sierra 1500 Extended Cab 2007-09	1017C			01			C5		E5			
Sierra 1500 Regular Cab 1991-94	1001B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Sierra 1500 Regular Cab 1995-98	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Sierra 1500 Regular Cab 1999-00	1012B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12,86	10,A3	11,80,08,85		13,16,A2	14,19		
Sierra 1500 Regular Cab 2001-06	1012B/C		UTC110 (8)	01	12,86	A3	80,85		A2	19		
Sierra 1500 Regular Cab 2007-09	1017C		UTC110 (8)	01			C5		E5			
Sierra 2500 Crew Cab 2001-02	1012B/C (1,5)	GMA110/SYT108 (1,5)	UTC110 (1,5,8)	01	12,86	A3	80,85		A2	19		
Sierra 2500 Crew Cab 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Sierra 2500 Crew Cab 2007-09	1017C (1)	GMA110 (1)		01			C5		E5			
Sierra 2500 Extended Cab 1991-94	1001B/C			01	12	10	11,08		13	14		
Sierra 2500 Extended Cab 1995-98	1007B/C			01	12	A3	11,80		16			
Sierra 2500 Extended Cab 1999-06	1012B/C	GTX110/AMP		01	86,12	A3	80,85		A2	19		
Sierra 2500 Extended Cab 2007-09	1017C			01			C5		E5			
Sierra 2500 Regular Cab 1991-94	1001B/C		UTC110 (8)	01	12	10	11,08		13	14		
Sierra 2500 Regular Cab 1995-98	1007B/C		UTC110 (8)	01	12	A3	11,80		16			
Sierra 2500 Regular Cab 1999-00	1012B/C (2)	GMT110 (2)		01	12,86	10,A3	11,80,08,85		13,16,A2	14,19		
Sierra 2500 Regular Cab 2001-06	1012B/C			01	12,86	A3	80,85		A2	19		
Sierra 2500 Regular Cab 2007-09	1017C		UTC110 (8)	01			C5		E5			
Sierra 3500 Crew Cab 2001-02	1012B/C (1,5)	GMA110/SYT108 (1,5)	UTC110 (1,5,8)	01	12,86	A3	80,85		A2	19		
Sierra 3500 Crew Cab 2003-06	1012B/C (1)	GMA110 (1)		01	12,86	A3	80,85		A2	19		
Sierra 3500 Crew Cab 2007-09	1017C (1)	GMA110 (1)		01			C5		E5			
Sierra 3500 Extended Cab 1991-94	1001B/C			01	12	10	11,08		13	14		
Sierra 3500 Extended Cab 1995-98	1007B/C			01	12	A3	11,80		16			
Sierra 3500 Extended Cab 1999-06	1012B/C	GTX110/AMP		01	86,12	A3	80,85		A2	19		
Sierra 3500 Extended Cab 2007-09	1017C			01			C5		E5			

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
<b>GMC</b>												
Sierra 3500 Regular Cab 1991-94	1001B/C		UTC110 (8)	01	12	10	11,08		13	14		
Sierra 3500 Regular Cab 1995-98	1007B/C		UTC110 (8)	01	12	A3	11,80		16			
Sierra 3500 Regular Cab 1999-00	1012B/C (2)	GMT110 (2)		01	12,86	10,A3	11,80,08,85		13,16,A2	14,19		
Sierra 3500 Regular Cab 2001-06	1012B/C			01	12,86	A3	80,85		A2	19		
Sierra 3500 Regular Cab 2007-09	1017C		UTC110 (8)	01			C5		E5			
Sierra Classic 1500 Ext Cab 1999-00	1007B/C	GMX110D/P		01	12	10,A3	11,80,08		13,16			
Sierra Classic 1500 Ext Cab 2007	1012B/C	GTX110/AMP		01	86,12	A3	80,85		A2	19		
Sierra Classic 1500 Reg Cab 1996-00	1007B/C	GMX110P	UTC110 (8)	01	12	10,A3	11,80,08		13,16			
Sierra Classic 1500 Reg Cab 2007	1012B/C		UTC110 (8)	01	12,86	A3	80,85		A2	19		
Sierra Classic 2500 Crew Cab 2003-07	1012B/C (1)	GMA110 (1)	UTC110 (1,8)	01	12,86	A3	80,85		A2	19		
Sierra Classic 2500 Ext Cab 2007	1012B/C	GTX110/AMP		01	86,12	A3	80,85		A2	19		
Sierra Classic 2500 Reg Cab 1999-00	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Sierra Classic 3500 Crew Cab 2003-07	1012B/C (1)	GMA110 (1)	UTC110 (1,8)	01	12,86	A3	80,85		A2	19		
Sierra Classic 3500 Ext Cab 2007	1012B/C	GTX110/AMP		01	86,12	A3	80,85		A2	19		
Sierra Classic 3500 Reg Cab 1999-00	1007B/C (2)	GMT110 (2)	UTC110 (2,8)	01	12	10,A3	11,80,08		13,16	14		
Sonoma Crew Cab 2003-04	1004B/C			01	12		11		13,A2	19		
Sonoma Extended Cab 1994-03	1004B/C			01	12		11		13,A2	19		
Sonoma Regular Cab 1994-03	1004B/C	GMS110	UTC110 (8)	01	12		11		13,A2	19		
<b>Honda</b>												
Accord 1990-93	6003B/C			01	40	41	42	46	43	44		
Accord 1994-97	6004B/C			01			42,55		43			45
Accord 1998-02	6006B/C			01	40		A5,B2			44		
Accord 2003-07	6008B/C			01			B2		43			
Civic 1988-91	6001B/C			01	40	83	42,55		43	44		
Civic 1992-95	6002B/C			01	40		42,55	46	43	44		45
Civic 1996-00	6005B/C			01			A5		43	44		
Civic 2001-05	6007B/C	HCV110		01			B2		43			
CRV 1997-00	6005B/C			01			A5		43	44		
CRX 1988-91	6001B/C			01	40	83	42,55		43	44		
Ridgeline 2006-09		HRL210		01								
<b>Hummer</b>												
H2 2003-07	1015B/C			01			D5					
H2 SUT 2005-07	1015B/C			01			D5					

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Isuzu												
Isuzu												
Hombre Regular Cab 1996-99	1004B/C	GMS110	UTC110 (8)	01	12		11		13,A2	19		
Hombre Regular Cab 2000	1004B/C			01	12		11		13,A2	19		
Hombre Spacecab 1996-99	1004B/C			01	12		11		13,A2	19		
Jeep												
Cherokee 1984-96	3002B/C			01			61		62			
Cherokee 1997-01	3010B/C			01			B9,B7		A1	93		
Grand Cherokee 1993-95	3005B/C	JGC110		01		35	33,91		34			
Grand Cherokee 1996-98	3009B/C	JGC110		01		35	33,91,B9		A1	93		
Wrangler 1997-06	3014C		WRG110	01								
Lexus												
ES 300 1992-96	4004B/C			01		88		87		90		
Lincoln												
Mark LT 2006-08	2013B/C	FTX110		01			D8		D9			
Navigator 1998-02	2010B/C (9)	EXP108/110		01		95	96		56	A6		57
Mazda												
B-Series 1994	2002B/C			01	24,03,22	28,02,2337,38,04,26			21	25	07	
B-Series 1995-09	2004B/C			01	22	23,95	05,96		56	A6		57
Navajo 1991-94	2005B/C	EXP108/110		01	24,22	28,23	04,26		21	25		
Mercedes Benz												
C-Class 1994-99	1101B			01	68		71	70	72			
Mercury												
Mountaineer 1997-01		EXP108/110		01								
Sable 1992-95	2009B/C			01	24,22	58,60	26		21			59
Mitsubishi												
Eclipse 1990-94	3003B/C			01			91		92	93		
Eclipse 1995-99	3004B/C (4)			01	A0		94	98		99		
Nissan												
Altima 1998-01	8003B/C			01			C9		D4			D3
Hardbody 1986-96	8001B/C			01	48	49		50	51	52		
Maxima 2000-03	8002B/C			01					C6			
Pathfinder 1987-95	8001B/C			01	48	49		50	51	52		
Titan King Cab 2004-09		GTX110		01	86		80,85		A2	19		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Oldsmobile												
Oldsmobile												
Alero 1999-04	1013B/C			01			78,85			19		
Bravada 1991	1003B/C			01	12	10	11		13	15		
Bravada 1992-95	1013B/C			01			78,85			19		
Bravada 1996-01	1004B/C			01	12		11		13,A2	19		
Bravada 2002-04	1016B/C (3)	GTE110 (3)		01			C0,C5,73	E3	73	E2		
Cutlass 1978-87	1011B/C			01	12	10	11			14		
Plymouth												
Laser 1990-94	3003B/C			01			91		92	93		
Pontiac												
Firebird 1982-92	1002B/C	ECF210/212		01	12	17	11,81,09			14		
Firebird 1993-02	1005B/C	CFT210/212		01		18	11,80		16,13	19,75,14		
Grand Am 1999-05	1013B/C			01			78,85			19		
Grand Prix 1978-87	1011B/C			01	12	10	11			14		
Grand Prix 1997-03	1014B/C			01			80			19		
Sunbird 1989-94	1008B/C (4)			01	77,76		94,78		13,16	14,19		
Sunfire 1995-96	1009B/C (4)			01	76		80		16	19		
Sunfire 1997-05	1010B/C (4)			01			80		A2	19		
Trans Am 1982-92	1002B/C	ECF210/212		01	12	17	11,81,09			14		
Trans Am 1993-02	1005B/C	CFT210/212		01		18	11,80		16,13	19,75,14		
Scion												
xB 2004-06	4007C			01						93		
Toyota												
4Runner 1989-95	4002B/C			01	54			87		29		
4Runner 1996-02	4003B/C	T4R110		01			32	87	D0	63		
Camry 1992-96	4004B/C			01		88		87		90		
Sequoia 2001-09	4005B/C			01			32		D0	90		
Tacoma 1995-04	4003B/C			01			32	87	D0	63		
Tacoma 2005-09	4006C			01			E1		D7			
Pickup (Std Cab) 1986-95	4002B/C	TRC110		01	54			87		29		
Tundra Access Cab 2000-06	4005B/C	TTX208		01			32		D0	90		
Tundra Double Cab 2004-06	4005B/C			01			32		D0	90		
Tundra Regular Cab 2000-06	4005B/C			01			32		D0	90		

Make, Model and Year	Q-Forms (QL-K)	Q-Customs (QL-C1)	Universal	Black	Blue	Red	Tan	Brown	LT Gray	Dk Gray	White	Green
Volkswagen												
Volkswagen												
Golf 1994-98	1201B			01			78,73			73		
Golf 1999-04	1202B/C			01			C5			16		
Jetta 1994-98	1201B			01			78,73			73		
Jetta 1999-04	1202B/C			01			C5			16		

**Footnotes**

- 1 Fits vehicles with second-row bench seats
- 2 Only fits long jack tray versions
- 3 Does not fit extended 7-passenger versions
- 4 Will not fit convertible models
- 5 Use of rear seat air vents may be lost when so equipped
- 6 Does not fit tailgate versions
- 7 Driver's side box does not fit 2-door vehicles
- 8 Does not fit extended cab trucks
- 9 Additional installation time required for adjustable pedals
- 10 Does not fit 318Ti

**Installation Tips**

QL-K1001	1-1/2-inch parking brake bend required
QL-K1003	Use supplied plastic housing & trim pattern for models with A/C
QL-K1004	1-1/2-inch parking brake bend required
QL-K1005	Requires cutting of factory piece to join with the Q-Form
QL-K1006	Q-Form mounts on top of factory kick panel if equipped
QL-K1007	1-1/2-inch parking brake bend required
QL-K1009	Requires cutting of factory piece to join with the Q-Form
QL-K1010	Requires cutting of factory piece to join with the Q-Form
QL-K1011	1-1/2-inch parking brake bend required Some models require relocation of factory computer (CPM)
QL-K1012	1-1/2-inch parking brake bend required
QL-K1013	Requires cutting of factory piece to join with the Q-Form
QL-K1101	1/2-inch parking brake bend required
QL-K1201	Requires relocation of hood release Must relocate factory wiring harness in passenger kick panel
QL-K2002	Panel flexes along center to fit as far down/back as possible
QL-K2003	Requires removal of factory footrest
QL-K2004	Panel flexes along center to fit as far down/back as possible
QL-K2005	1-1/2-inch parking brake bend required
QL-K2006	1-1/2-inch parking brake bend required
QL-K2008	Requires relocation of hood release to underside of dash
QL-K2009	1/2-inch parking brake bend required
QL-K2010	1/2-inch parking brake bend required
QL-K2012	Requires removal of factory footrest
QL-K2014	Use of factory footrest is lost
QL-K3001	1-1/2-inch parking brake bend required Cut factory piece to join with Q-Form
QL-K3002	Rests close to clutch in manual transmissions
QL-K3003	Use of factory footrest is lost
QL-K3004	Use of factory footrest is lost
QL-K3005	Requires removal of factory footrest
QL-K3007	3/4-inch parking brake bend required
QL-K3008	3/4-inch parking brake bend required
QL-K3009	Requires removal of factory footrest
QL-K3011	Requires cutting of factory piece to join with the Q-Form
QL-K3012	Requires removal of factory footrest
QL-K4002	Fits around factory computer Use of factory footrest is lost
QL-K4003	Use of factory footrest is lost
QL-K4004	Requires removal of factory footrest
QL-K4007	Use of factory footrest is lost
QL-K6001	Cut factory piece to join with Q-Form Requires removal of factory footrest
QL-K6002	Requires removal of factory footrest Requires removal of factory plastic hood release housing
QL-K6003	Requires removal of factory footrest
QL-K6004	Some models require relocation of factory computer (CPM) Requires removal of factory footrest
QL-K6005	Use of factory footrest is lost
QL-K6006	Requires removal of factory footrest
QL-K6007	Requires removal of factory footrest
QL-K6008	Requires relocation of hood release Requires removal of factory footrest
QL-K7001	Some models require relocation of factory computer (CPM) Requires removal of factory footrest
QL-K7002	Requires removal of factory footrest
QL-K8001	Rests close to clutch in manual transmissions
QL-K8002	Requires cutting of factory piece to join with the Q-Form